



Solder right angle male headers to the GPIO board
Need a 2x10 header and a 1x4 header


Use Male->Female dupont wires like these :

To connect J7 on SC1000 to GPIO board



SDA
SCL
GND
VCC

CONNECT



Connect buttons between COM and one of the numbers

